

## 3. Components & .NET

- The Baseplate 1004 component default tolerance was changed to 6mm for the baseplate holes. The previous default was much larger.
- The following 3 pre-saved component settings for Splice 77 component have been created:
  - standard.j77
  - Same\_side\_attachment.j77
  - Aternate\_attachment.j77

Standard.j77 & Aternate\_attachment.j77 are the same. They have been setup to turn all the welds to Shop welds so that you get the correct result when choosing a bolted/welded case via the parameters tab page. They also now follow more closely the standard splice types used in Australasia.

- We have streamlined the “Macro’s” folder and removed unusable and obsolete macro’s. We also added the very useful support tool which can help send support the users machine and Tekla info, plus locate the environment files, and user files etc.

